

Hand Sanitizer Stand™ - HST Series

1. Connect Upright to Base bushing using large Philips head screw provided.
2. Connect the hand sanitizer holder to the top of the upright using the flat head Phillips head screw provided.
3. Loosen the knob clamp (if needed), by turning the knob counter-clockwise and place the base of your hand sanitizer bottle into the tray. Tighten the knob clamp, by turning the knob clockwise, to secure the sanitizer bottle in place.
4. **FOR TELESCOPIC UPRIGHT ONLY:** Loosen the clutch by turning it 1/4 turn counter-clockwise, raise or lower the upright as needed, then turn the clutch 1/4 turn clockwise to lock the height of the upright.

